

Pump Test Instructions

⚠️ When Carrying out a pump test with the MIDAS installed please follow the attached Instructions. ⚠️

1. Carry out pump test as procedure.
2. To reintroduce the Fuel back into the storage tank:
 - Obtain the Green MIDAS Engineers keyfob from the PFS
 - This will need to be signed out and back in once work is complete.
 - Unlock the cap on the OSF
 - Attach the cam lock funnel adaptor to the part A of the OSF and insert the funnel
 - Activate the MIDAS using the Engineers keyfob by shaking briefly and then holding the key fob **label side down** above the indicator panel. The key must be held at least 10 cm directly above the indicator panel and must be stationary when activating unit
 - In this mode the MIDAS will activate and open the valve for a period of 10 minutes. To indicate that the unit is active the red green and amber LED's will flash in sequence throughout the 10 minutes. At the 9:30 mark the sounder will start beeping to indicate that the valve is about to close. If still required the unit will need reactivating after this.



Once complete the valve will shut down after 10 minutes.



Any Queries Please contact a member of the team during office hours on – 0121 558 4411